en **Service manual**

Wheel loader

Document ID

Order number: 11632018
Issued: 06-2019
Version: 07

Product ID

Valid for: L 506-1258

Contents

010 Introduction 010-1

010.1 Safety instructions 010-3

010.1.1 General safety instructions 010-3

010.1.2 Instructions on preventing crushing injuries and burns 010-4

010.1.3 Instructions on preventing fires and explosions 010-4

010.1.4 Safety instructions for start-up 010-5

010.1.5 Safety precautions during start-up 010-5

010.1.6 Instructions for safe working 010-6

010.1.7 Safety instructions for driving on slopes 010-7

010.1.8 Parking safely 010-7

010.1.9 Transporting the machine safely 010-7

010.1.10 Towing the machine safely 010-8

010.1.11 Measures for ensuring safe maintenance 010-8

010.1.12 Safety instructions for maintenance work on machines with hydro accumulators 010-11

010.1.13 Safety instructions for welding work on the machine 010-11

010.1.14 Safety instruction for working on the working attachment 010-11

010.1.15 Safety instructions for transporting the machine by crane 010-12

010.1.16 Safe maintenance of hydraulic hoses and hose lines 010-12

010.1.17 Roll over protective structure (ROPS) and falling object protection structure (FOPS) 010-13

010.1.17.1 Preventing accidents 010-13

010.1.17.2 Preventing injuries 010-13

010.1.18 Attachments and accessories 010-13

010.1.19 Protection against vibrations 010-14

010.1.20 See and be seen 010-14

010.1.20.1 Field of view and visual aids 010-14

010.1.20.2 Measures during operation. 010-15

010.1.20.3 Modifications to the machine 010-15

010.1.21 Danger area of the machine 010-15

LBH/11632018/07/211-20190529_121029/en

010.2 Special tools for maintenance and repair work 010-17
010.2.1 Special tools in general 010-17
010.2.2 Special tools for the diesel engine 010-17
010.2.3 Special tools for Z kinematics hydraulic cylinders 010-18
010.2.4 Special tools for steering cylinders 010-18
010.2.5 Special tools for the electrical system 010-18
010.2.6 Special tools for axles 010-19
010.2.7 Special tools for the air conditioning system 010-19
010.2.8 Special tools for cab glazing 010-20
010.2.9 Special tools for the central lubrication system 010-20
010.3 Standards and regulations 010-21
010.3.1 Prestressing forces and tightening torques for bolts with metric standard and fine threads as per DIN ISO 261 010-21
010.3.1.1 Range of application and purpose 010-21
010.3.1.2 Other applicable documents 010-21
010.3.1.3 Modifications and descriptions 010-22
010.3.1.4 Tightening torques 010-22
010.3.2 Liebherr standards for assembly instructions and tightening torques 010-28
010.4 Preservation guidelines 010-29
010.4.1 General information 010-29
010.4.2 Machine out of service for an unknown period of time 010-29
010.4.3 Putting the machine out of service 010-30
010.4.3.1 Out of service for up to 2 months 010-30
010.4.3.2 Out of service for up to 12 months 010-31
010.4.3.3 Out of service for longer than 12 months 010-32
010.4.4 Putting back into service 010-32
010.4.4.1 After being out of service for 2 months 010-32
010.4.4.2 After being out of service for 12 months 010-33
010.4.4.3 After being out of service for longer than 12 months 010-33

020 Technical data 020-1
020.1 Overall machine 020-4
020.1.1 Complete machine with loading bucket *L506-1258/30398-;* 020-4
020.1.2 Working attachment: 4 in 1 bucket *L506-1258/30398-;* 020-5

LBH/11632018/07/211-20190529_121029/en

020.1.3 Working attachment: forklift
L506-1258/30398-; 020-7

020.2 Drive group 020-9

020.2.1 Diesel engine
L506-1258/30398-; 020-9

020.2.2 Fuel tank
L506-1258/30398-; 020-10

020.2.3 Fuel level sensor
L506-1258/30398-; 020-10

020.2.4 Fuel pre-filter
L506-1258/30398-; 020-11

020.2.5 Fuel fine filter
L506-1258/30398-; 020-11

020.2.6 Air filter vacuum switch
L506-1258/30398-; 020-11

020.2.7 Clutch
L506-1258/30398-; 020-11

020.3 Cooling system 020-12

020.3.1 Water cooler
L506-1258/30398-; 020-12

020.4 Working hydraulics 020-13

020.4.1 Working hydraulics pump
L506-1258/30398-; 020-13

020.4.2 Control valve block
L506-1258/30398-; 020-13

020.4.3 Z-bar kinematics lift cylinder
L506-1258/30398-; 020-14

020.4.4 Z kinematics tilt cylinder
L506-1258/30398-; 020-14

020.5 Travel hydraulics 020-15

020.5.1 Travel pump
L506-1258/30398-; 020-15

020.5.2 Travel motor
L506-1258/30398-; 020-16

020.6 Hydraulic components 020-17

020.6.1 Hydraulic oil temperature switch
L506-1258/30398-; 020-17

020.6.2 Filter unit
L506-1258/30398-; 020-17

020.6.3 Breather filter
L506-1258/30398-; 020-17

020.7 Steering system 020-18

LBH/11632018/07/211-20190529_121029/en

020.7.1 Servostat
L506-1258/30398-; 020-18

020.7.2 Steering cylinder
L506-1258/30398-; 020-18

020.8 Brake system 020-19

020.8.1 Drum brake
L506-1258/30398-; 020-19

020.8.2 Brake master cylinder
L506-1258/30398-; 020-19

020.8.3 Brake light pressure switch B12
L506-1258/30398-; 020-19

020.9 Electrical system 020-20

020.9.1 Battery
L506-1258/30398-; 020-20

020.10 Gearbox 020-21

020.10.1 Transmission
L506-1258/30398-; 020-21

020.11 Axles and drive shafts 020-22

020.11.1 Front axle
L506-1258/30398-; 020-22

020.11.2 Rear axle
L506-1258/30398-; 020-22

020.11.3 Drive shaft
L506-1258/30398-; 020-23

020.11.4 Tyres
L506-1258/30398-; 020-23

020.11.4.2 Special tyres 020-24

020.12 Steel parts of the basic machine 020-25

020.12.1 Ballast weight
L506-1258/30398-; 020-25

020.13 Working attachment 020-26

020.13.1 Lift arms for Z kinematics
L506-1258/30398-; 020-26

020.13.2 Quick coupler
L506-1258/30398-; 020-26

020.14 Operator's cab, heating and air conditioning 020-27

020.14.1 Heating, air conditioning
L506-1258/30398-; 020-27

020.14.2.1 Air conditioning 020-27

020.14.3.1 Air conditioning compressor 020-27

020.14.4.1 Dryer 020-28

020.14.5.1 Air conditioning pressure switch 020-28

LBH/1163201 8/07/211-20190529_121029/en

020.14.6 Anti-icing thermostat
L506-1258/30398-; 020-28

020.15 Lubrication system 020-29

020.15.1 Central lubrication pump EP1
L506-1258/30398-; 020-29

020.15.2 Progressive distributor
L506-1258/30398-; 020-29

020.15.2.1 MX-F 020-29

020.15.2.2 MX-F 25 020-29

020.15.2.3 MX-F 45 020-30

020.15.2.4 MX-F 75 020-30

020.15.2.5 MX-F105 020-30

030 Maintenance 030-1

030.1 Maintenance and inspection schedule 030-7

030.2 Filling quantities and lubrication chart 030-12

030.2.1 Recommended lubricants
L506-1258/30398-; 030-12

030.2.2 Recommended operating fluids
L506-1258/30398-; 030-13

030.3 Lubricants and fuels 030-14

030.3.1 General information on lubricants and fuels 030-14

030.3.1.1 General questions 030-14

030.3.1.2 Safety data sheets 030-14

030.3.1.3 Technical data sheets 030-14

030.3.1.4 Specific Liebherr standards 030-14

030.3.2 General information on changing lubricants and fuels 030-14

030.3.3 Converting hydraulic system from mineral oils to biodegradable hydraulic fluids 030-15

030.3.4 Diesel fuels
L506-1258/30398-; 030-15

030.3.4.1 Specification 030-15

030.3.4.2 Sulphur content in the diesel fuel 030-15

030.3.4.2 Diesel fuel lubricity 030-15

030.3.4.3 Diesel fuel at low temperatures (winter operation) 030-16

030.3.5 Lubricating oils for diesel engines
L506-1258/30398-; 030-16

030.3.5.1 Lubricating oil quality 030-16

030.3.5.2 Lubricating oil viscosity 030-16

LBH/11632018/07/211-20190529_121029/en

030.3.6 Refrigerant
L506-1258; 030-17

030.3.7 Coolants for diesel engines
L506-1258/30398-; 030-17

030.3.7.1 General recommendations 030-17

030.3.7.2 Water (fresh water) 030-18

030.3.7.3 Coolant - Mixing ration 030-18

030.3.7.4 Permissible antifreeze and corrosion inhibitors 030-19

030.3.7.5 Corrosion inhibitors without antifreeze 030-19

030.3.8 Hydraulic oil
L506-1258/30398-; 030-20

030.3.8.1 Liebherr hydraulic oil 030-20

030.3.8.2 Using engine oil as hydraulic oil 030-20

030.3.8.3 Warming up 030-21

030.3.8.4 Biodegradable hydraulic oils 030-21

030.3.8.5 Changing the oil, analysing the oil, changing filters 030-22

030.3.9 Lubricating oils for axles and transmissions
L506-1258/30398-; 030-23

030.3.10 Brake oil
L506-1258/30398-; 030-24

030.3.10.2 Service brake 030-24

030.3.11 Lubrication grease and other lubricants
L506-1258/30398-; 030-24

030.3.11.1 Minimum quality requirements 030-25

030.3.11.2 Liebherr lubrication grease 030-25

030.4 Maintenance tasks 030-27

030.4.1 Safety precautions
L506-1258/30398-; 030-27

030.4.2 Preparatory tasks for maintenance 030-27

030.4.2.1 Maintenance positions
L506-1258/30398-; 030-28

030.4.2.2 Opening the service hatches
L506-1258/30398-; 030-29

030.4.2.3 Turning off battery main switch
L506-1258/30398-; 030-30

030.4.3 Overall machine 030-31

030.4.3.1 Checking the machine for external damage
L506-1258/30398-; 030-31

030.4.3.2 Removing loose parts, dirt, ice and snow from the machine
L506-1258/30398-; 030-31

LBH/11632018/07/211-20190529_121029/en

	030.4.3.3	Cleaning the machine *L506-1258/30398-;*	030-32
	030.4.3.4	Checking the machine for leaks *L506-1258/30398-;*	030-33
	030.4.3.5	Making sure the bolted connections are tight *L506-1258/30398-;*	030-33
	030.4.3.6	Corrosion protection system for use with salt and artificial fertilisers (optional): Carrying out corrosion protection *L506-1258/30398-;*	030-34
	030.4.3.7	Oil analyses *L506-1258/30398-;*	030-34
030.4.4	Drive group		030-41
	030.4.4.1	Checking the engine oil level *L506-1258/30398-;*	030-41
	030.4.4.2	Changing the engine oil *L506-1258/30398-;*	030-41
	030.4.4.3	Changing the engine oil filter *L506-1258/30398-;*	030-43
	030.4.4.4	Checking diesel engine V-belt *L506-1258/30398-;*	030-44
	030.4.4.5	Changing the engine V-belt *L506-1258/30398-;*	030-46
	030.4.4.6	Checking the engine valve clearance *L506-1258/30398-;*	030-48
	030.4.4.7	Draining condensate and sediment from fuel tank *L506-1258/30398-;*	030-52
	030.4.4.8	Draining off condensate from the fuel pre-filter *L506-1258/30298-30397; L506-1258/30398-;*	030-53
	030.4.4.9	Cleaning the fuel pre-filter *L506-1258/30398-;*	030-54
	030.4.4.10	Changing the fuel fine filter *L506-1258/30398-;*	030-55
	030.4.4.11	Cleaning service cover and dust discharge valve of air filter system *L506-1258/30398-;*	030-57
	030.4.4.12	Checking the air suction system for leaks and tight fitting *L506-1258/30398-;*	030-58
	030.4.4.13	Testing the air filter vacuum switch *L506-1258/30398-;*	030-59
	030.4.4.14	Cleaning or changing the main filter element *L506-1258/30398-;*	030-60
	030.4.4.15	Changing the air filter safety element *L506-1258/30398-;*	030-63

LBH/11632018/07/211-20190529_121029/en

	030.4.4.16	Checking the exhaust system for leaks and tight fitting *L506-1258/30398-;*	030-64
030.4.5	Cooling system		030-65
	030.4.5.1	Checking coolant level in cooling system *L506-1258/30398-;*	030-65
	030.4.5.2	Checking the coolant antifreeze and corrosion inhibitor concentration *L506-1258/30398-;*	030-67
	030.4.5.3	Cleaning the cooling system *L506-1258/30398-;*	030-71
	030.4.5.4	Changing coolant (at least once a year) *L506-1258/30398-;*	030-72
030.4.6	Hydraulic components		030-74
	030.4.6.1	Checking oil level in hydraulic tank *L506-1258/30398-;*	030-74
	030.4.6.2	Draining off condensate and sediment from the hydraulic tank *L506-1258/30398-;*	030-76
	030.4.6.3	Hydraulic tank - changing the return-suction filter *L506-1258/30398-;*	030-77
	030.4.6.4	Changing the hydraulic tank breather filter *L506-1258/30398-;*	030-79
	030.4.6.5	Changing oil in hydraulic system *L506-1258/30398-;*	030-79
030.4.7	Steering system		030-81
	030.4.7.1	Testing the steering *L506-1258/30398-;*	030-81
	030.4.7.2	Lubricating steering cylinder bearing *L506-1258/30398-;*	030-82
030.4.8	Brake system		030-83
	030.4.8.1	Testing service brake and parking brake *L506-1258/30398-;*	030-83
	030.4.8.2	Checking oil level in brake system *L506-1258/30398-;*	030-84
	030.4.8.3	Checking the gap and wear on the service brake linings *L506-1258/30398-;*	030-85
030.4.9	Electrical system		030-86
	030.4.9.1	Checking the lights *L506-1258/30398-;*	030-86
	030.4.9.2	Checking the batteries, fluid level and terminals *L506-1258/30398-36021;*	030-87

LBH/1163201 8/07/211-20190529_121029/en

	030.4.9.3	Checking the batteries, fluid level and terminals *L506-1258/36022-;*	030-89
	030.4.9.4	Changing the travel direction rocker switch and cap (optional) on the control lever *L506-1258/30398-;*	030-92
030.4.10	Gearbox		030-94
	030.4.10.1	Checking the transmission oil level *L506-1258/30398-;*	030-94
	030.4.10.2	Changing the transmission oil *L506-1258/30398-;*	030-94
030.4.11	Axles and drive shafts		030-95
	030.4.11.1	Checking the axle oil levels *L506-1258/30398-;*	030-95
	030.4.11.2	Changing the axle oil *L506-1258/30398-;*	030-96
	030.4.11.3	Checking the tightening torque of the fastening bolts *L506-1258/30398-;*	030-97
	030.4.11.4	Checking the cardan shafts *L506-1258/30398-;*	030-98
	030.4.11.5	Checking the tyre pressure *L506-1258/30398-;*	030-98
	030.4.11.6	Checking the wheel tightness *L506-1258/30398-37498;*	030-99
	030.4.11.7	Checking wheel tightness *L506-1258/37499-;*	030-99
030.4.12	Steel parts of the basic machine		030-100
	030.4.12.1	Lubricating articulated bearing *L506-1258/30398-;*	030-100
	030.4.12.2	Lubricating articulation stops *L506-1258/30398-;*	030-101
	030.4.12.3	Covering - lubricating locks and hinges *L506-1258/30398-;*	030-101
030.4.13	Working attachment		030-102
	030.4.13.1	Lubricating the lift arms and working attachment *L506-1258/30398-;*	030-102
	030.4.13.2	Checking the lift arm bearing bushings *L506-1258/30398-;*	030-103
	030.4.13.3	Checking the lift arm bucket stops *L506-1258/30398-;*	030-103
	030.4.13.4	Lubricating and testing the quick-change device *L506-1258/30398-;*	030-104
030.4.14	Operator's cab, heating and air conditioning		030-105
	030.4.14.1	Cleaning operator's cab air filter *L506-1258/30398-;*	030-105

LBH/11632018/07/211-20190529_121029/en

030.4.14.2 Changing operator's cab air filter
L506-1258/30398-; 030-106

030.4.14.3 Checking the condition and function of the safety belt
L506-1258/30398-; 030-107

030.4.14.4 Filling windscreen washer fluid in windscreen washer system
L506-1258/30398-; 030-108

030.4.14.5 Checking the seals on the driver's cab
L506-1258/30398-; 030-108

030.4.14.6 Air conditioning: draining condensate
L506-1258/30398-; 030-109

030.4.14.7 Testing the air conditioning unit
L506-1258/30398-; 030-109

030.4.15 Lubrication system 030-111

030.4.15.1 Checking central lubrication system grease reservoir level
L506-1258/30398-; 030-111

030.4.15.2 Checking the pipes, hoses and lubrication points of the lubrication system
L506-1258/30398-; 030-111

030.4.15.3 Checking whether metered quantities are adequate at the bearing points (grease collars) of the lubrication system
L506-1258/30398-; 030-112

030.5 Testing and adjustment checklist
L506-1258/30398-; 030-113

030.6 Testing and adjustment tasks 030-116

030.6.1 Safety precautions
L506-1258/30398-; 030-116

030.6.2 Overall machine 030-117

030.6.2.1 Testing and adjusting: Preparation
L506-1258/30398-; 030-117

030.6.2.2 Hydraulic system: operating temperature
L506-1258/30398-; 030-118

030.6.3 Drive group 030-118

030.6.3.1 Engine: Speed
L506-1258/30398-; 030-118

030.6.4 Working hydraulics 030-120

030.6.4.1 Control valve block: Primary pressure relief valve
L506-1258/30398-; 030-120

030.6.5 Hydraulic components 030-122

030.6.5.1 Checking the hydraulic lines for damage
L506-1258; 030-122

030.6.6 Travel hydraulics 030-127

LBH/1163201 8/07/211-20190529_121029/en

030.6.6.1 Travel pump: Replenishing pressure relief valve
L506-1258/30398-; 030-127

030.6.6.2 Blocked condition
L506-1258/30398-; 030-128

030.6.6.3 Travel pump: Control valve
L506-1258/30398-; 030-129

030.6.6.4 Travel pump: Pump output
L506-1258/30398-; 030-130

030.6.6.5 Travel pump: High pressure relief valves
L506-1258/30398-; 030-132

030.6.6.6 Travel pump: Pressure cut-off
L506-1258/30398-; 030-134

030.6.6.7 Travel motor: Regulation range
L506-1258/30398-; 030-135

030.6.7 Steering system 030-137

030.6.7.1 Servostat: LS pressure relief valve
L506-1258/30398-; 030-137

030.6.8 Brake system 030-138

030.6.8.1 Inch/brake pedal: Idle path
L506-1258/30398-; 030-138

030.6.8.2 Inch/brake pedal: Inching valve leakage
L506-1258/30398-; 030-138

030.6.9 Operator's cab, heating and air conditioning 030-139

030.6.9.1 Setting the service hours in the display
L506-1258/30398-; 030-139

040 Drive group 040-1

040.1 Engine 040-2

040.1.1 Diesel engine overview
L506-1258/30398-; 040-2

040.1.2 Engine control unit (ECU)
L506-1258/30398-; 040-13

040.1.3 Preglow system
L506-1258/30398-; 040-16

040.1.4 Engine speed sensor
L506-1258/30398-; 040-17

040.1.5 Fuel system 040-17

040.1.5.1 Overview of the fuel system
L506-1258/30398-; 040-18

040.1.5.2 Fuel level sensor
L506-1258/30398-; 040-18

040.1.5.3 Fuel pre-filter
L506-1258/30398-; 040-20

LBH/11632018/07/211-20190529_121029/en

040.1.5.4 Fuel pre-delivery pump
L506-1258/30398-; 040-21

040.1.5.5 Fuel fine filter
L506-1258/30398-; 040-22

040.1.6 Air filter system 040-22

040.1.6.1 Overview of the air filter unit
L506-1258/30398-; 040-23

040.1.6.2 Air filter
L506-1258/30398-; 040-24

040.1.6.3 Vacuum switch for air filter
L506-1258/30398-; 040-25

050 Cooling system 050-1

050.1 Overview of the cooling system
L506-1258/30398-; 050-2

050.2 Cooler 050-3

050.2.1 Water cooler
L506-1258/30398-; 050-3

050.2.2 Hydraulic oil cooler
L506-1258/30398-; 050-5

060 Working hydraulics 060-1

060.1 Overview of working hydraulics
L506-1258/30398-; 060-2

060.2 Working hydraulics pump
L506-1258/30398-; 060-5

060.3 Control valve block
L506-1258/30398-; 060-9

060.4 Hydraulic cylinders of the working hydraulics 060-19

060.4.1 Hydraulic cylinders for Z kinematics 060-19

060.4.1.1 Z kinematics lift cylinder
L506-1258/30398-; 060-19

060.4.1.2 Z kinematics tilt cylinder
L506-1258/30398-; 060-20

070 Travel hydraulics 070-1

070.1 Travel hydraulics overview
L506-1258/30398-; 070-2

070.2 Travel pump
L506-1258/30398-; 070-5

070.3 Travel motors 070-19

070.3.1 Travel motor
L506-1258/30398-; 070-19

LBH/1163201 8/07/211-20190529_121029/en

080 Hydraulic components 080-1

080.1 Hydraulic tank 080-2

080.1.1 Overview of the hydraulic tank
L506-1258/30398-; 080-2

080.1.2 Filtration grade
L506-1258/30398-; 080-4

080.1.3 Breather filter
L506-1258/30398-; 080-10

090 Steering system 090-1

090.1 Steering system overview
L506-1258/30398-; 090-2

090.2 Servostat
L506-1258/30398-; 090-5

090.3 Steering cylinder 090-9

090.3.1 Steering cylinder overview
L506-1258/30398-; 090-9

100 Brake system 100-1

100.1 Overview of the brake system
L506-1258/30398-; 100-2

100.2 Service brake and parking brake 100-4

100.2.1 Drum brake
L506-1258/30398-; 100-4

100.3 Service brake 100-8

100.3.1 Overview of the service brake
L506-1258/30398-; 100-8

100.3.2 Inch/brake pedal
L506-1258/30398-; 100-10

100.3.3 Inching valve
L506-1258/30398-; 100-11

100.3.4 Brake master cylinder
L506-1258/30398-; 100-13

100.3.5 Brake light pressure switch
L506-1258/30398-; 100-17

100.3.6 Brake fluid equalising reservoir
L506-1258/30398-; 100-18

100.4 Parking brake 100-19

100.4.1 Overview of the parking brake
L506-1258/30398-; 100-19

100.4.2 Parking brake switch
L506-1258/30398-; 100-20

LBH/11632018/07/211-20190529_121029/en

110 Electrical system 110-1

110.1 Overview of the electrical system
L506-1258/30398-; 110-2

110.2 Lighting
L506-1258/30398-; 110-6

110.3 Circuit diagrams
L506-1258/30398-; 110-8

110.4 Electrical components of the driver's cab 110-10

110.4.1 Fuse and relay board A4
L506-1258/30398-; 110-10

110.5 Electrical components in the rear section 110-13

110.5.1 Battery installation
L506-1258/30398-; 110-13

120 Gearbox 120-1

120.1 Overview of the transmission
L506-1258/30398-; 120-2

130 Axles and drive shafts 130-1

130.1 Axles 130-2

130.1.1 Front axle
L506-1258/30398-; 130-2

130.1.2 Rear axle
L506-1258/30398-; 130-6

130.2 Cardan shafts 130-10

130.2.1 Cardan shaft
L506-1258/30398-; 130-10

140 Steel parts of the basic machine 140-1

140.1 Vehicle frame 140-2

140.1.1 Articulation bearing
L506-1258/30398-; 140-2

140.1.2 Articulation lock
L506-1258/30398-; 140-3

140.2 Ballast weight
L506-1258/30398-; 140-4

140.3 Covering 140-5

140.3.1 Engine hood
L506-1258/30398-; 140-5

LBH/1163201 8/07/211-20190529_121029/en

150 Working attachment 150-1

150.1 Lift arms for Z kinematics 150-2

150.1.1 Z kinematics lift arms
L506-1258/30398-; 150-2

150.2 Quick coupler 150-4

150.2.1 Quick coupler
L506-1258/30398-; 150-4

160 Operator's cab, heating and air conditioning 160-1

160.1 Overall view of the driver’s cab
L506-1258/30398-; 160-3

160.2 Display and control elements 160-5

160.2.1 Electrical components in the control panel 160-5

160.2.1.1 Overview of electrical components in the control panel
L506-1258/30398-; 160-5

160.2.2 Display
L506-1258/30398-; 160-6

160.2.3 Control lever
L506-1258/30398-; 160-10

160.2.4 Accelerator pedal
L506-1258/30398-; 160-11

160.3 Heating, ventilation, air conditioning 160-13

160.3.1 Overview of heating, ventilation and air conditioning system
L506-1258/30398-; 160-13

160.3.2 Heating and air conditioning unit 160-18

160.3.2.1 Heating and air conditioning unit
L506-1258/30398-; 160-19

160.3.2.2 Blower
L506-1258/30398-; 160-20

160.4 Air conditioning 160-22

160.4.1 Basic function of the air conditioning unit
L506-1258/30398-; 160-22

160.4.2 Air conditioning compressor
L506-1258/30398-; 160-23

160.4.3 Condenser
L506-1258/30398-; 160-28

160.4.4 Dryer
L506-1258/30398-; 160-28

160.4.5 Air conditioning pressure switch
L506-1258/30398-; 160-29

LBH/11632018/07/211-20190529_121029/en

170 Lubrication system 170-1

170.1 Liebherr automatic central lubrication system 170-2

170.1.1 Automatic central lubrication system: overview
L506-1258/30398-; 170-2

170.1.2 Central lubrication pump EP-1
L506-1258/30398-; 170-6

170.1.3 Progressive distributor MX-F
L506-1258/30398-; 170-9

190 Options 190-1

190.1 LiDAT 190-2

190.1.1 Overview of LiDAT
L506-1258/30398-; 190-2

190.1.2 LiDAT on the machine
L506-1258/30398-; 190-4

200 Diagnosis 200-1

200.1 Malfunctions 200-2

200.1.1 Warning symbols 200-2

200.1.2 Troubleshooting 200-3

200.1.9 Service code indicator in the display 200-5

200.1.9.1 Service code table 200-6

200.1.9.1 Display service code table 200-9

200.2 Troubleshooting 200-10

200.2.1 Replacing fuses 200-10

200.2.1.1 Fuses in the battery compartment 200-10

200.2.1.2 Plug-in fuses on the relay and fuse board 200-11

200.2.1.3 Plug-in fuses for LiDAT 200-12

LBH/11632018/07/211-20190529_121029/en

BUY NOW

PayPal VISA MasterCard DISCOVER AMERICAN EXPRESS

Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com