en

Service manual

Telescopic handler

Document ID

Order number: 12231156
Issued: 01.05.2019
Version: 03

Product ID

Valid for: T 33-10-1695 4F

Contents

010 Introduction 010-1

010.1 Safety instructions 010-4

010.1.1 Safety instructions for crushing and burn prevention 010-4

010.1.2 Safety guidelines for fire and explosion prevention 010-4

010.1.3 Safety guidelines for machine start up 010-5

010.1.4 Safety instruction for start up 010-5

010.1.5 Safety guidelines for working 010-5

010.1.6 Safety guidelines for turning the machine off 010-7

010.1.7 Safety guidelines for transporting the machine 010-7

010.1.8 Working in the vicinity of electrical overhead lines 010-8

010.1.9 Safety instructions for towing the machine 010-9

010.1.10 Safety guidelines for maintenance 010-9

010.1.11 Safety guidelines for welding work on the machine 010-12

010.1.12 Safety guidelines for working on the working attachment 010-12

010.1.13 Safety guidelines for loading the machine with a crane 010-12

010.1.14 Safety notes for maintenance of hydraulic hoses and hose lines 010-13

010.1.15 Safety guidelines for maintenance work on machines with hydro accumulators 010-13

010.1.16 Roll over protection (ROPS) and falling object protection (FOPS) 010-14

010.1.16.1 Avoid accidents 010-14

010.1.16.2 Avoid injuries 010-14

010.1.17 Equipment and attachment parts 010-14

010.1.18 Protection from vibrations 010-15

010.1.19 Safety guidelines for machine application in material handling operation 010-15

010.1.20 Safety instructions for machine application with quick coupler 010-16

010.2 Special tools for maintenance and repair work 010-17

010.2.1 Tools - Diesel engine 010-17

010.2.2 Tools - Hydraulic system 010-18

010.2.3 Tools - Hydraulic cylinder 010-20

LWT/12231156/03/215-20190426_0957742/en

	010.2.4	Tools - Electrical system	010-21
	010.2.5	Tools - Counterweight	010-24
	010.2.6	Tools - Telescopic boom	010-24
010.3	Standards and specifications		010-26
	010.3.1	Preload values and tightening torques for screws with standard and fine metric thread according to DIN ISO 261	010-26
		010.3.1.1 Scope of application and purpose	010-26
		010.3.1.2 Further applicable documentation	010-26
		010.3.1.3 Changes and descriptions	010-27
		010.3.1.4 Tightening values	010-27
		010.3.1.5 Flanges and half flanges for high pressure (standard 62)	010-33
		010.3.1.6 Half flange for low pressure (standard 61)	010-33
		010.3.1.7 Tightening torques for cutting edges, end bits and adapters	010-33
	010.3.2	Installation specifications	010-34
		010.3.2.1 Duo cone slipring seals	010-34
	010.3.3	Tapping bores	010-36
		010.3.3.1 Tapping bores of metric ISO standard threads	010-36
		010.3.3.2 Tapping bores of metric ISO fine threads	010-38
	010.3.4	Conversion tables	010-41
010.4	Conservation guidelines		010-42
	010.4.1	General	010-42
	010.4.2	Taking the machine out of service for an unknown duration	010-42
	010.4.3	Shut down of the machine	010-43
		010.4.3.1 Shut down for up to 2 months	010-43
		010.4.3.2 Shut down for up to 12 months	010-44
		010.4.3.3 Shut down for longer than 12 months	010-45
	010.4.4	Return to operation	010-45
		010.4.4.1 After a shut down of 2 months	010-45
		010.4.4.2 After a shut down of 12 months	010-45
		010.4.4.3 After shut down of longer than 12 months	010-46
010.5	Repair welding		010-47
	010.5.1	Preparation of cracked part	010-47
	010.5.1	Preparation of a weld	010-48
	010.5.1	Treatment of electrodes	010-48

LWT/122311156/03/215-20190426_095742/en

010.5.1 Welding technique 010-48

010.5.1 Reinforcement of welding seam 010-49

010.5.1 General use of reinforcement sheeting 010-49

010.5.1.1 Form of sheeting 010-49

010.5.1.1 Thickness of sheeting 010-49

010.5.1.1 Material quality of sheeting 010-50

010.5.1.1 Application of reinforcement sheeting 010-50

010.5.1.1 Welding the reinforcement sheeting 010-50

010.5.1.1 Selection of correct welding electrodes 010-51

010.5.1.2 Electrode selection 010-51

010.5.1.2 Steel chart 010-52

010.5.1.2 Welding additives chart 010-53

010.6 Hydraulic symbols 010-57

010.7 Electrical symbols 010-67

010.8 Material weights 010-71

020 Technical data 020-1

020.1 Overall machine 020-3

020.1.1 Complete machine - Overview
T33-10-1695-4FLO/15752-; 020-3

020.2 Drive group 020-5

020.2.1 Diesel engine, full overview
T33-10-1695-4FLO/15752-; 020-5

020.2.1.1 Technical data 020-5

020.2.2 Alternator - Full overview
T33-10-1695-4FLO/15752-; 020-6

020.2.2.1 Technical data 020-6

020.2.3 Starter - Full overview
T33-10-1695-4FLO/15752-; 020-6

020.2.3.1 Technical data 020-6

020.2.4 Fuel tank - Full overview
T33-10-1695-4FLO/15752-; 020-6

020.2.4.1 Technical data 020-6

020.3 Cooling system 020-7

020.3.1 Double gear pump
T33-10-1695-4FLO/15752-; 020-7

020.3.2 Gear motor
T33-10-1695-4FLO/15752-; 020-7

LWT/12231156/03/215-20190426_0957742/en

020.4 Working hydraulics 020-8

020.4.1 Double gear pump
T33-10-1695-4FLO/15752-; 020-8

020.4.2 Proportional control valve block
T33-10-1695-4FLO/15752-; 020-8

020.4.3 Lift cylinder
T33-10-1695-4FLO/15752-; 020-9

020.4.4 Tilt cylinder (standard kinematics)
T33-10-1695-4FLO/15752-; 020-9

020.4.5 Balancing cylinder
T33-10-1695-4FLO/15752-; 020-9

020.4.6 Telescopic cylinder
T33-10-1695-4FLO/15752-; 020-9

020.4.7 Level regulation cylinder
T33-10-1695-4FLO/15752-; 020-10

020.5 Travel hydraulics 020-11

020.5.1 Axial piston variable displacement pump
T33-10-1695-4FLO/15752-; 020-11

020.5.2 Variable displacement motor
T33-10-1695-4FLO/15752-; 020-11

020.6 Hydraulic components 020-12

020.6.1 Hydraulic tank
T33-10-1695-4FLO/15752-; 020-12

020.7 Electrical system 020-13

020.7.1 Batteries
T33-10-1695-4FLO/15752-; 020-13

020.7.2 Fuses
T33-10-1695-4FLO/15752-; 020-13

020.8 Travel gear, axles, tyres, drive shafts 020-14

020.8.1 Axles
T33-10-1695-4FLO/15752-; 020-14

030 Maintenance 030-1

030.1 Maintenance and inspection schedule 030-7

030.2 Fill quantities, lubrication schedule 030-12

030.2.1 Recommended fuel and operating fluids
T33-10-1695-4FLO; 030-12

030.2.2 Lubrication schedule
T33-10-1695-4FLO; 030-12

030.3 Lubricants and fuels 030-15

030.3.1 General Specifications 030-15

LWT/122311156/03/215-20190426_095742/en

030.3.2	Diesel fuels *T33-10-1695-4FLO;*		030-15
	030.3.2.1	Minimum quality requirement	030-15
030.3.3	Engine oils *T33-10-1695-4FLO;*		030-16
	030.3.3.1	Liebherr recommendation	030-16
	030.3.3.1	Other approved engine oils	030-16
	030.3.3.2	Minimum quality requirement	030-16
	030.3.3.3	Aggravating circumstances	030-16
030.3.4	Coolant *T33-10-1695-4FLO;*		030-17
	030.3.4.1	Requirements for water used	030-17
	030.3.4.2	Corrosion inhibitor	030-17
	030.3.4.2	Liebherr recommendation	030-17
	030.3.4.2	Anti-freeze and corrosion protection agent	030-17
	030.3.4.2	Liebherr recommendation	030-17
	030.3.4.2	Minimum quality requirement	030-18
030.3.5	Diesel exhaust fluids *T33-10-1695-4FLO;*		030-18
	030.3.5.1	Liebherr recommendation	030-18
	030.3.5.2	Minimum quality requirement	030-18
030.3.6	Hydraulic oil *T33-10-1695-4FLO;*		030-18
	030.3.6.1	Liebherr Hydraulic oil	030-18
	030.3.6.2	Engine oil as hydraulic oil	030-19
	030.3.6.3	Warm up specification	030-20
	030.3.6.4	Biodegradable hydraulic oils	030-20
	030.3.6.5	Oil change, oil analysis, filter change	030-21
030.3.7	Lube oils for travel gearbox *T33-10-1695-4FLO;*		030-23
	030.3.7.1	Quality	030-23
	030.3.7.2	Viscosity	030-24
030.3.8	Lube oils for axles *T33-10-1695-4FLO;*		030-24
	030.3.8.1	Quality	030-24
030.3.9	Oil for the brake system *T33-10-1695-4FLO;*		030-25
	030.3.9.1	Quality	030-25

LWT/12231156/03/215-20190426_0957742/en

030.3.10 Grease for the telescopic boom
T33-10-1695-4FLO; 030-25

030.3.11 Grease and other lubricants
T33-10-1695-4FLO/15752-; 030-25

030.3.12 Oil for hinges and joints
T33-10-1695-4FLO; 030-27

030.4 Maintenance tasks 030-28

030.4.1 Maintenance - preparations 030-28

030.4.1.1 Maintenance position
T33-10-1695-4FLO; 030-28

030.4.1.2 Turn the electrical system off
T33-10-1695-4FLO; 030-33

030.4.2 Overall machine 030-33

030.4.2.1 Checking machine for external damage
T33-10-1695-4FLO; 030-33

030.4.2.2 Lubricating the machine
T33-10-1695-4FLO; 030-33

030.4.2.3 Wet cleaning the machine
T33-10-1695-4FLO; 030-39

030.4.2.4 Protect the piston rods
T33-10-1695-4FLO; 030-39

030.4.2.5 Taking the machine out of service
T33-10-1695-4FLO; 030-40

030.4.3 Drive group 030-40

030.4.3.1 Diesel engine - check oil level
T33-10-1695-4FLO; 030-40

030.4.3.2 Diesel engine: Changing oil and oil filter
T33-10-1695-4FLO; 030-41

030.4.3.3 Checking engine compartment for contamination and cleaning it, if necessary
T33-10-1695-4FLO; 030-44

030.4.3.4 Diesel engine: checking and changing ribbed V-belt
T33-10-1695-4FLO; 030-44

030.4.3.5 Checking diesel engine for leaks
T33-10-1695-4FLO; 030-46

030.4.3.6 Diesel engine: checking intake and exhaust system for condition, mounting and leaks
T33-10-1695-4FLO; 030-47

030.4.3.7 Diesel engine: checking cable connections of sensors
T33-10-1695-4FLO; 030-48

030.4.3.8 Diesel engine: checking mounting tightness of engine brackets
T33-10-1695-4FLO; 030-48

LWT/122311156/03/215-20190426_0957742/en

	030.4.3.9	Diesel exhaust fluid pump - changing the filter *T33-10-1695-4FLO;*	030-48
	030.4.3.10	Notes for working on the fuel system *T33-10-1695-4FLO;*	030-49
	030.4.3.11	Draining the fuel pre-filter condensation *T33-10-1695-4FLO;*	030-49
	030.4.3.12	Fuel tank: draining condensation and sediments *T33-10-1695-4FLO;*	030-50
	030.4.3.13	Fuel: changing filter cartridges *T33-10-1695-4FLO;*	030-51
	030.4.3.15	Air filter system: changing air filter *T33-10-1695-4FLO;*	030-53
	030.4.3.16	Air filter: cleaning the service cover and dust discharge valve *T33-10-1695-4FLO;*	030-56
030.4.4	Cooling system		030-57
	030.4.4.1	Cooling system: checking the coolant level *T33-10-1695-4FLO;*	030-57
	030.4.4.2	Cooling system: checking radiator and condenser for contamination and cleaning them, if necessary *T33-10-1695-4FLO;*	030-59
	030.4.4.3	Checking the cooling system for leaks and damage *T33-10-1695-4FLO;*	030-60
	030.4.4.4	Cooling system: checking antifreeze concentration in the coolant *T33-10-1695-4FLO;*	030-61
	030.4.4.5	Cooling system: changing coolant *T33-10-1695-4FLO/15615-;*	030-63
030.4.5	Travel hydraulics		030-65
	030.4.5.1	Changing the supply circuit filter *T33-10-1695-4FLO;*	030-65
030.4.6	Hydraulic components		030-66
	030.4.6.1	Checking the oil level in the hydraulic tank and topping up oil *T33-10-1695-4FLO;*	030-66
	030.4.6.2	Changing the tank vent filter on the hydraulic tank *T33-10-1695-4FLO;*	030-67
	030.4.6.3	Checking the hydraulic system for leaks *T33-10-1695-4FLO;*	030-68
	030.4.6.4	Changing the hydraulic oil *T33-10-1695-4FLO;*	030-68
	030.4.6.5	Changing return filter insert *T33-10-1695-4FLO;*	030-70
030.4.7	Steering system		030-72

LWT/12231156/03/215-20190426_0957742/en

	030.4.7.1	Checking function of steering system *T33-10-1695-4FLO;*	030-72
030.4.8	Brake system		030-73
	030.4.8.1	Service brake and parking brake: check function and effectiveness *T33-10-1695-4FLO;*	030-73
	030.4.8.2	Brake system: Checking oil level in the expansion tank *T33-10-1695-4FLO;*	030-75
	030.4.8.3	Brake system: Checking brake linings for wear *T33-10-1695-4FLO;*	030-76
030.4.9	Electrical system		030-79
	030.4.9.1	Electrical system: Checking function of load torque limitation *T33-10-1695-4FLO;*	030-79
	030.4.9.2	Checking lighting *T33-10-1695-4FLO;*	030-83
	030.4.9.3	Checking the battery connections for tight seating *T33-10-1695-4FLO;*	030-83
	030.4.9.4	Battery: checking the condition and correct routing of the degassing hose *T33-10-1695-4FLO;*	030-86
030.4.10	Travel gear, axles, tyres, drive shafts		030-87
	030.4.10.1	Wheels: checking mounting tightness of wheel lugs *T33-10-1695-4FLO;*	030-87
	030.4.10.2	Wheels: checking and adjusting air pressure in tyres *T33-10-1695-4FLO;*	030-88
	030.4.10.3	Checking oil level of axles *T33-10-1695-4FLO;*	030-90
	030.4.10.4	Changing oil in the axles *T33-10-1695-4FLO;*	030-91
	030.4.10.5	Axles: Checking tightening torques of axle mounting screws *T33-10-1695-4FLO;*	030-93
030.4.11	Steel components Basic machine		030-94
	030.4.11.1	Checking front glide elements for wear and tight seating. Lubricating slide faces on telescopic boom *T33-10-1695-4FLO;*	030-94
	030.4.11.2	Checking rear glide elements for wear and tight seating *T33-10-1695-4FLO;*	030-97
030.4.12	Operator's cab, heating, air conditioning		030-97
	030.4.12.1	Check drier unit *T33-10-1695-4FLO;*	030-97

LWT/122311156/03/215-20190426_0957742/en

030.4.12.2 Heating and air conditioning: checking the function
T33-10-1695-4FLO; 030-98

030.4.12.3 Clean and change the heating - fresh air filter
T33-10-1695-4FLO; 030-99

030.4.12.4 Air conditioning
T33-10-1695-4FLO; 030-100

030.4.12.5 Checking the drain valves for the air conditioning and cleaning them if necessary
T33-10-1695-4FLO; 030-101

030.4.13 Lubrication system 030-102

030.4.13.1 Grease container: check the fill level
T33-10-1695-4FLO; 030-102

030.4.14 Options 030-103

030.4.14.1 Air brake system: draining pressure tank
T33-10-1695-4FLO; 030-103

030.4.14.2 Air brake system
T33-10-1695-4FLO; 030-103

030.5 Testing and adjustment checklist
T33-10-1695-4FLO/15752-; 030-106

030.5.1 Adjustment checklist 030-106

030.5.1.1 Section A - Preparation for hydraulic test 030-106

030.5.1.2 Section B - Testing with standard test equipment 030-108

030.5.1.3 Section C - Component calibration and function test with Plus+1 diagnostics software 030-121

030.6 Testing and adjustment tasks 030-124

030.6.1 Safety instructions
T33-10-1695-4FLO; 030-124

030.6.2 Overall machine 030-125

030.6.2.1 Preparations for adjustment procedures
T33-10-1695-4FLO/15752-; 030-125

030.6.2.2 Visual inspection and maintenance
T33-10-1695-4FLO/15752-; 030-126

030.6.2.3 Bringing machine to operating temperature
T33-10-1695-4FLO/15752-; 030-127

030.6.3 Cooling system 030-128

030.6.3.1 Fan drive pressure limitation
T33-10-1695-4FLO/15752-; 030-128

030.6.4 Working hydraulics 030-128

030.6.4.1 Checking the high pressure working hydraulics on the control valve block
T33-10-1695-4FLO/15752-; 030-128

030.6.4.2 Checking the pilot pressure of the working hydraulics
T33-10-1695-4FLO/15752-; 030-129

LWT/12231156/03/215-20190426_0957742/en

030.6.4.3 Check the secondary pressure relief valve on the control valve block
T33-10-1695-4FLO/15752-; 030-130

030.6.5 Travel hydraulics 030-132

030.6.5.1 Checking the replenishing pressure for var. displ. pump
T33-10-1695-4FLO/15752-; 030-132

030.6.5.2 Checking the mechanical zero position of the variable displacement pump
T33-10-1695-4FLO/15752-; 030-133

030.6.5.3 Check the pressure limitation - High pressure
T33-10-1695-4FLO/15752-; 030-133

030.6.6 Steering system 030-135

030.6.6.1 Check the regulating pressure steering cylinder
T33-10-1695-4FLO/15752-; 030-135

030.6.7 Brake system 030-136

030.6.7.1 Checking the brake pressure when the parking brake is open
T33-10-1695-4FLO/15752-; 030-136

030.6.7.2 Checking the brake pressure when the parking brake is closed
T33-10-1695-4FLO/15752-; 030-136

030.6.7.3 Check the brake pressure of the service brake
T33-10-1695-4FLO/15752-; 030-137

030.6.8 Electrical system 030-137

030.6.8.1 Save parameters
T33-10-1695-4FLO/15752-; 030-137

030.6.8.2 Carrying out a high pressure test
T33-10-1695-4FLO/15752-; 030-137

030.6.8.3 Carrying out boom angle sensor calibration
T33-10-1695-4FLO/15752-; 030-138

030.6.9 Travel gear, axles, tyres, drive shafts 030-138

030.6.9.1 Check the tyre pressure
T33-10-1695-4FLO/15752-; 030-138

040 Drive group 040-1

040.1 Diesel engine 040-2

040.1.1 Diesel engine – Full overview
T33-10-1695-4FLO/15752-; 040-2

040.1.2 Fuel system 040-16

040.1.2.1 Fuel system - Full overview
T33-10-1695-4FLO/15752-; 040-16

040.1.2.2 Fuel quantity sensor
T33-10-1695-4FLO/15752-; 040-20

LWT/122311156/03/215-20190426_0957742/en

040.1.2.3 Fuel pre-filter
T33-10-1695-4FLO/15752-; 040-21

040.1.2.4 Fuel fine filter
T33-10-1695-4FLO/15752-; 040-22

040.1.2.5 Fuel tank
T33-10-1695-4FLO/15752-; 040-25

040.1.3 Air filter system 040-26

040.1.3.1 Air filter system - Full overview
T33-10-1695-4FLO/15752-; 040-27

040.1.4 Exhaust system 040-29

040.1.4.1 Exhaust system - full overview
T33-10-1695-4FLO/15752-; 040-30

040.1.4.2 Diesel particle filter (option)
T33-10-1695-4FLO/15752-; 040-31

040.1.4.3 SCR system
T33-10-1695-4FLO/15752-; 040-34

040.1.5 Diesel engine mounting
T33-10-1695-4FLO/15752-; 040-38

040.2 Clutch
T33-10-1695-4FLO/15752-; 040-40

050 Cooling system 050-1

050.1 Cooling system - Full overview
T33-10-1695-4FLO/15752-17046; 050-2

050.2 Cooling system - Full overview
T33-10-1695-4FLO/17047-; 050-9

050.3 Cooler arrangement 050-16

050.3.1 Combi cooler
T33-10-1695-4FLO/15752-; 050-16

050.4 Hydraulic 050-18

050.4.1 Gear pump
T33-10-1695-4FLO/15752-; 050-18

050.4.2 Gear motor - Fan
T33-10-1695-4FLO/15752-; 050-19

060 Working hydraulics 060-1

060.1 Working hydraulics - Full overview
T33-10-1695-4FLO/15752-17046; 060-2

060.2 Working hydraulics - Full overview
T33-10-1695-4FLO/17047-; 060-18

060.3 Gear pump
T33-10-1695-4FLO/15752-; 060-35

060.4 Pilot control Working hydraulic 060-37

LWT/12231156/03/215-20190426_0957742/en

060.4.1 Control lever
T33-10-1695-4FLO/15752-; 060-37

060.5 Hydraulic cylinder 060-42

060.5.1 Hydraulic cylinder - Full overview
T33-10-1695-4FLO/15752-; 060-42

060.5.2 Lift cylinder - Full overview
T33-10-1695-4FLO/15752-; 060-44

060.5.3 Balancing cylinder - Full overview
T33-10-1695-4FLO/15752-; 060-47

070 Travel hydraulics 070-1

070.1 Travel hydraulics - Full overview
T33-10-1695-4FLO/15752-; 070-2

070.2 Variable displacement pump
T33-10-1695-4FLO/15752-; 070-9

070.3 Variable displacement motors 070-15

070.3.1 Variable displacement motors - full overview
T33-10-1695-4FLO/15752-; 070-15

080 Hydraulic components 080-1

080.1 Hydraulic system - Full overview
T33-10-1695-4FLO/15752-; 080-2

080.2 Hydraulic cylinder 080-3

080.2.1 Valves
T33-10-1695-4FLO/15752-; 080-3

080.3 Hydraulic tank 080-16

080.3.1 Hydraulic tank
T33-10-1695-4FLO/15752-; 080-16

090 Steering system 090-1

090.1 Steering system - Full overview
T33-10-1695-4FLO/15752-17046; 090-2

090.2 Steering system - Full overview
T33-10-1695-4FLO/17047-; 090-12

090.3 Steering aggregate
T33-10-1695-4FLO/15752-; 090-22

090.4 Steering cylinder
T33-10-1695-4FLO/15752-; 090-24

100 Brake system 100-1

100.1 Brake system - Full overview
T33-10-1695-4FLO/15752-; 100-2

LWT/122311156/03/215-20190426_095742/en

100.2 Valve block 100-9

100.2.1 Valve block - Full overview
T33-10-1695-4FLO/15752-; 100-9

100.3 Pressure accumulator
T33-10-1695-4FLO/15752-; 100-11

100.4 Inching brake pedal 100-12

100.4.1 Inching brake pedal
T33-10-1695-4FLO/15752-; 100-12

110 Electrical system 110-1

110.1 Electrical system - full overview
T33-10-1695-4FLO/15752-; 110-2

110.2 Lighting - Full overview
T33-10-1695-4FLO/15752-; 110-6

110.3 Circuit diagrams
T33-10-1695-4FLO/15752-; 110-9

110.4 Cab electrical system - Full overview
T33-10-1695-4FLO/15752-; 110-10

110.5 Electrical components - Diesel engine - Full overview
T33-10-1695-4FLO/15752-; 110-23

110.6 Electrical system - Telescope 10 m - Full overview
T33-10-1695-4FLO/15752-; 110-29

110.7 Electrical components Compartments 110-32

110.7.1 Battery compartment
T33-10-1695-4FLO/15752-; 110-33

110.7.2 Electrical components - Central electrical system
T33-10-1695-4FLO/15752-; 110-37

110.8 Display unit
T33-10-1695-4FLO/15752-; 110-41

110.9 Electrical components - LIDAT
T33-10-1695-4FLO/15752-; 110-46

130 Travel gear, axles, tyres, drive shafts 130-1

130.1 Multiple disk brake
T33-10-1695-4FLO/15752-; 130-2

130.2 Differential gear
T33-10-1695-4FLO/15752-; 130-7

130.3 Wheel hub with steering axle
T33-10-1695-4FLO/15752-; 130-13

130.4 Gear shaft
T33-10-1695-4FLO/15752-; 130-15

130.5 DMS sensor installation 130-16

130.5.1.1 Assembly preparation 130-16

LWT/12231156/03/215-20190426_0957742/en

130.5.1.2 Gluing process 130-17

130.6 Load torque display
T33-10-1695-4FLO/15752-; 130-19

140 Steel components Basic machine 140-1

140.1 Telescopic boom 10m
T33-10-1695-4FLO/15752-; 140-2

160 Operator's cab, heating, air conditioning 160-1

160.1 Operator’s platform 160-2

160.1.1 Operator's cab
T33-10-1695-4FLO/15752-; 160-2

160.1.2 Operator's cab mount
T33-10-1695-4FLO/15752-; 160-5

160.2 Operator's cab 160-7

160.2.1 Operator's seat with mechanical suspension
T33-10-1695-4FLO/15752-; 160-7

160.3 Heating, ventilation, air conditioning 160-8

160.3.1 Heating, ventilation, air conditioning - Full overview
T33-10-1695-4FLO/15752-; 160-8

160.3.2 Heating and air conditioning system 160-12

160.3.2.1 Double radial fan DRG 980
T33-10-1695-4FLO/15752-; 160-13

170 Lubrication system 170-1

170.1 Standard lubrication system - Full overview
T33-10-1695-4FLO/15752-; 170-2

170.2 Manual central lubrication system
T33-10-1695-4FLO/15752-; 170-8

170.3 Automatic central lubrication system 170-11

170.3.1 Automatic central lubrication system - Full overview
T33-10-1695-4FLO/15752-; 170-11

170.3.2 Control and operation of central lubrication pump
T33-10-1695-4FLO/15752-; 170-12

190 Options 190-1

190.1 Reversible fan drive
T33-10-1695-4FLO/15752-17046; 190-2

190.2 Reversible fan drive
T33-10-1695-4FLO/17047-; 190-10

190.3 Hoist gear suspension
T33-10-1695-4FLO/15752-17046; 190-18

LWT/12231156/03/215-20190426_0957742/en

190.4 Hoist gear suspension
T33-10-1695-4FLO/17047-; 190-28

190.5 Hydraulic trailer brake - 1-line
T33-10-1695-4FLO/17047-; 190-38

190.6 External pressure relief control circuit 3
T33-10-1695-4FLO/15752-; 190-46

190.7 Electrically reversible control circuit 3
T33-10-1695-4FLO/15752-; 190-53

190.8 Electrically reversible control circuit 3 with external pressure relief
T33-10-1695-4FLO/15752-; 190-61

190.9 Liebherr quick coupler
T33-10-1695-4FLO/17047-; 190-70

190.10 Manitou quick coupler
T33-10-1695-4FLO/15752-; 190-80

190.11 Scorpion quick coupler
T33-10-1695-4FLO/15752-; 190-88

190.12 Control circuit 4 switchable from control circuit 3
T33-10-1695-4FLO/15752-; 190-96

200 Service codes, Diagnostics 200-1

200.1 Malfunctions 200-3

200.1.1 Service code list 200-3

200.2 Testing and adjustment software 200-61

200.2.1 Software accessories 200-61

200.2.1.1 CANFox-OBD Installation 200-61

200.2.1.2 Custloader installation 200-63

200.2.1.3 Casappa Bootloader Tool Installation 200-65

200.2.1.4 Plus+1 Service Tool Installation 200-65

200.2.2 Software update 200-66

200.2.2.1 Downloading the Update package 200-66

200.2.2.2 Display update using Custloader 200-67

200.2.2.3 Update using Casappa Bootloader Tool 200-71

200.2.2.4 Update using Plus+1 200-73

200.2.2.5 Selection of Service Technicians Tool 200-73

200.2.2.6 Exporting machine-specific parameters 200-77

200.2.2.7 Update Control units for working hydraulics and travel hydraulics 200-81

200.2.2.8 AllParameter Update control units 200-86

200.2.2.9 Importing machine-specific parameters 200-87

LWT/12231156/03/215-20190426_0957742/en

200.2.3	Plus+1 test and adjustment software		200-90
	200.2.3.1	Plus+1 test and adjustment software	200-90
	200.2.3.2	Interface structure	200-91
	200.2.3.3	Homepage	200-92
	200.2.3.4	System Overview - System overview	200-95
	200.2.3.5	Service - Test and calibration	200-98
	200.2.3.6	Electric Signals - Overview of electric signals	200-110
	200.2.3.7	Status I/0 - Error display	200-114
	200.2.3.8	Parameters	200-121

LWT/122311156/03/215-20190426_095742/en

Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com