en

Service manual

Crawler dozer

Document ID

Order number: 9087211
Issued: 01.09.2019
Version: 10

Product ID

Valid for: PR 746-1293
PR 746-1294

Contents

010 Introduction 010-1

010.1 Safety instructions 010-4

010.1.1 General safety instructions 010-4

010.1.2 Safety guidelines for crushing and burn prevention 010-5

010.1.3 Safety guidelines for fire and explosion prevention 010-5

010.1.4 Safety instructions for machine start up 010-6

010.1.5 Safety guidelines for start up 010-6

010.1.6 Safety guidelines for working 010-6

010.1.7 Safety guidelines for turning machine off 010-8

010.1.8 Safety instructions for transporting machine 010-8

010.1.9 Safety instructions for towing machine 010-8

010.1.10 Safety instructions for maintenance 010-9

010.1.11 Safety guidelines for welding work on machine 010-11

010.1.12 Safety guidelines for working on attachment 010-11

010.1.13 Safety guidelines for loading machine with a crane 010-12

010.1.14 Safety notes for maintenance of hydraulic hoses and hose lines 010-12

010.1.15 Safety guidelines for maintenance work on machines with hydro accumulators 010-13

010.1.16 Roll over protection (ROPS) and falling object protection (FOPS) 010-13

010.1.16.1 Avoid accidents 010-13

010.1.16.2 Avoid injuries 010-14

010.1.17 Equipment and attachment parts 010-14

010.1.18 Protection from vibrations 010-14

010.1.19 See and be seen 010-15

010.1.19.1 Field of vision 010-15

010.1.19.2 Measures before and during operation 010-16

010.1.20 Safety notes for Diesel engines with electronic control units 010-16

010.1.21 Safety notes for working on Common Rail System of Diesel engines 010-17

010.2 Special tools for maintenance and repair work 010-19

010.2.1 Tools - Diesel engine 010-19

LWT/9087211/10/215-20190905_090946/en

010.2.2 Tools - Hydraulic system 010-21
010.2.3 Tools - Hydraulic cylinder 010-26
010.2.4 Tools - Electrical system 010-27
010.2.5 Tools - Travel gearbox 010-29
010.2.6 Tools - Travel gear 010-30
010.2.7 Tension unit tools 010-31
010.2.8 Lift cylinder suspension tools 010-32
010.2.9 Tools - Oscillating axle frame 010-33
010.2.10 Tools - Diesel exhaust fluid system 010-34
010.3 Standards and specifications 010-36
010.3.1 Preload values and tightening torques for screws with standard and fine metric thread according to DIN ISO 261 010-36
010.3.1.1 Scope of application and purpose 010-36
010.3.1.2 Further applicable documentation 010-36
010.3.1.3 Changes and descriptions 010-37
010.3.1.4 Tightening values 010-37
010.3.1.5 Flanges and half flanges for high pressure (standard 62) 010-43
010.3.1.6 Half flange for low pressure (standard 61) 010-43
010.3.1.7 Tightening torques for cutting edges, end bits and adapters 010-43
010.3.2 Installation specifications 010-44
010.3.2.1 Duo cone slipring seals 010-44
010.3.3 Tapping bores 010-46
010.3.3.1 Tapping bores of metric ISO standard threads 010-46
010.3.3.2 Tapping bores of metric ISO fine threads 010-48
010.3.4 Conversion tables 010-51
010.4 Conservation guidelines 010-52
010.4.1 General 010-52
010.4.2 Taking the machine out of service for an unknown duration 010-52
010.4.3 Shut down of the machine 010-53
010.4.3.1 Shut down for up to 2 months 010-53
010.4.3.2 Shut down for up to 12 months 010-54
010.4.3.3 Shut down for longer than 12 months 010-55
010.4.4 Return to operation 010-55
010.4.4.1 After a shut down of 2 months 010-55

LWT/9087211/10/215-20190905_090946/en

010.4.4.2	After a shut down of 12 months	010-55
010.4.4.3	After shut down of longer than 12 months	010-56
010.5	Repair welding	010-57
010.5.1	Preparation of cracked part	010-57
010.5.1	Preparation of a weld	010-58
010.5.1	Treatment of electrodes	010-58
010.5.1	Welding technique	010-58
010.5.1	Reinforcement of welding seam	010-59
010.5.1	General use of reinforcement sheeting	010-59
010.5.1.1	Form of sheeting	010-59
010.5.1.1	Thickness of sheeting	010-59
010.5.1.1	Material quality of sheeting	010-60
010.5.1.1	Application of reinforcement sheeting	010-60
010.5.1.1	Welding the reinforcement sheeting	010-60
010.5.1.1	Selection of correct welding electrodes	010-61
010.5.1.2	Electrode selection	010-61
010.5.1.2	Steel chart	010-62
010.5.1.2	Welding additives chart	010-63
010.6	Hydraulic symbols	010-67
010.7	Electrical symbols	010-77
010.8	Material weights	010-81

020 Technical data 020-1

020.1	Overall machine	020-3
020.1.1	Overall machine - overview *PR746-1293/11216-; PR746-1294/11216-;*	020-3
020.2	Drive group	020-5
020.2.1	Diesel engine *PR746-1293/11216-; PR746-1294/11216-;*	020-5
020.2.2	Clutch *PR746-1293/11216-; PR746-1294/11216-;*	020-6
020.2.3	Splitterbox *PR746-1293/11216-; PR746-1294/11216-;*	020-6
020.3	Cooling system	020-8
020.3.1	Regulator pump for coolant circuit *PR746-1293/11216-; PR746-1294/11216-;*	020-8
020.3.2	Fan drive gear motor of hydraulic oil cooler *PR746-1293/11216-; PR746-1294/11216-;*	020-8

LWT/9087211/10/215-20190905_090946/en

020.3.3 Axial piston motor fan drive of water cooler and intercooler
PR746-1293/11216-; PR746-1294/11216-; 020-8

020.4 Working hydraulics 020-9

020.4.1 Regulating pump Working hydraulic
PR746-1293/11216-; PR746-1294/11216-; 020-9

020.4.2 Proportional control valve block
PR746-1293/11216-; PR746-1294/11216-; 020-9

020.4.3 Lift cylinder
PR746-1293/11216-; PR746-1294/11216-; 020-9

020.4.4 Tilt cylinder
PR746-1293/11216-; PR746-1294/11216-; 020-10

020.5 Travel hydraulics 020-11

020.5.1 Gear pump replenishing and pilot control working hydraulic
PR746-1293/11216-; PR746-1294/11216-; 020-11

020.5.2 Variable displacement pump
PR746-1293/11216-; PR746-1294/11216-; 020-11

020.5.3 Variable displacement motor
PR746-1293/11216-; PR746-1294/11216-; 020-11

020.6 Hydraulic components 020-12

020.6.1 Hydraulic tank
PR746-1293/11216-; PR746-1294/11216-; 020-12

020.7 Electrical system 020-13

020.7.1 Batteries - Installation
PR746-1293/11216-; PR746-1294/11216-; 020-13

020.8 Travel gearbox 020-14

020.8.1 Travel gear
PR746-1293/11216-; PR746-1294/11216-; 020-14

020.8.2 Brake system
PR746-1293/11216-; PR746-1294/11216-; 020-15

020.9 Travel gear, axles, tyres, drive shafts 020-16

020.9.1 Travel gear frame
PR746-1293/11216-; PR746-1294/11216-; 020-16

020.9.2 Idler
PR746-1293/11216-; PR746-1294/11216-; 020-16

020.9.3 Tension unit
PR746-1293/11216-; PR746-1294/11216-; 020-16

020.9.4 Track roller
PR746-1293/11216-; PR746-1294/11216-; 020-16

020.9.5 Carrier roller
PR746-1293/11216-; PR746-1294/11216-; 020-17

020.9.6 Track chain
PR746-1293/11216-; PR746-1294/11216-; 020-17

LWT/90872111/10/215-20190905_090946/en

020.9.7 Sprocket
PR746-1293/11216-; PR746-1294/11216-; 020-17

020.10 Working attachment 020-19

020.10.1 Straight blade
PR746-1293/11216-; PR746-1294/11216-; 020-19

020.10.2 Cutting angle adjustment for blade
PR746-1293/11216-; PR746-1294/11216-; 020-20

020.10.3 Ripper with cutting angle adjustment
PR746-1293/11216-; PR746-1294/11216-; 020-21

030 Maintenance 030-1

030.1 Maintenance and inspection schedule 030-8

030.2 Fill quantities, lubrication schedule 030-14

030.2.1 Recommended lubricants
PR746-1293/11216-; PR746-1294/11216-; 030-14

030.2.2 Recommended operating fluids
PR746-1293/11216-; PR746-1294/11216-; 030-15

030.2.3 Lubrication schedule
PR746-1293; PR746-1294; 030-15

030.3 Lubricants and fuels 030-18

030.3.1 General information about lubricants and fuels 030-18

030.3.1.1 General Information 030-18

030.3.1.2 General questions 030-18

030.3.1.3 Safety data sheets 030-18

030.3.1.4 Technical data sheets 030-18

030.3.1.5 Specific Liebherr standards 030-18

030.3.2 Diesel fuels
PR746-1293/11216-; PR746-1294/11216-; 030-19

030.3.2.1 Minimum quality requirement 030-19

030.3.3 Engine oils
PR746-1293/11216-; PR746-1294/11216-; 030-19

030.3.3.1 Liebherr recommendation 030-19

030.3.3.1 Other approved engine oils 030-19

030.3.3.2 Minimum quality requirement 030-19

030.3.3.3 Aggravating circumstances 030-20

030.3.4 Coolant
PR746-1293/11216-; PR746-1294/11216-; 030-20

030.3.4.1 Requirements for water used 030-20

030.3.4.2 Corrosion inhibitor 030-21

LWT/9087211/10/215-20190905_090946/en

	030.3.4.2	Liebherr recommendation	030-21
	030.3.4.2	Anti-freeze and corrosion protection agent	030-21
	030.3.4.2	Liebherr recommendation	030-21
	030.3.4.2	Minimum quality requirement	030-21
030.3.5	Diesel exhaust fluids *PR746-1293/11216-; PR746-1294/11216-;*		030-22
	030.3.5.1	Liebherr recommendation	030-22
	030.3.5.2	Minimum quality requirement	030-22
030.3.6	Hydraulic oil *PR746-1293/11216-; PR746-1294/11216-;*		030-22
	030.3.6.1	Liebherr Hydraulic oil	030-22
	030.3.6.2	Engine oil as hydraulic oil	030-23
	030.3.6.3	Warm up specification	030-23
	030.3.6.4	Biodegradable hydraulic oils	030-24
	030.3.6.5	Oil change, oil analysis, filter change	030-24
030.3.7	Lube oils for splitterboxes *PR746-1293/11216-; PR746-1294/11216-;*		030-27
	030.3.7.1	Quality	030-27
	030.3.7.2	Viscosity	030-28
030.3.8	Lube oils for travel gearbox *PR746-1293/11216-; PR746-1294/11216-;*		030-28
	030.3.8.1	Quality	030-28
	030.3.8.2	Viscosity	030-29
	030.3.8.3	Oil change	030-29
030.3.9	Oil for duo cone (slipring) seal Travel gear *PR746-1293; PR746-1294;*		030-29
030.3.10	Grease and other lubricants *PR746-1293/11216-; PR746-1294/11216-;*		030-30
030.3.11	Oil for hinges and joints *PR746-1293; PR746-1294;*		030-31
030.3.12	Oil for axle bearing *PR746-1293; PR746-1294;*		030-32
030.4	Maintenance tasks		030-33
030.4.1	Safety instructions for maintenance *PR746-1293; PR746-1294;*		030-33
030.4.2	Maintenance - preparations		030-33
	030.4.2.1	Maintenance position *PR746-1293/11216-; PR746-1294/11216-;*	030-33
	030.4.2.2	Turn the electrical system off *PR746-1293/11216-; PR746-1294/11216-;*	030-36

LWT/9087211/10/215-20190905_090946/en

	030.4.2.3	Raising the operator's cab hydraulically *PR746-1293/11216-; PR746-1294/11216-;*	030-36
	030.4.2.4	Lower the operator's cab hydraulically *PR746-1293/11216-; PR746-1294/11216-;*	030-39
030.4.3	Overall machine		030-41
	030.4.3.1	Checking the machine for external damage, correct maintenance and proper condition *PR746-1293; PR746-1294;*	030-41
	030.4.3.2	Lubricating all lube points according to lubrication chart *PR746-1293; PR746-1294;*	030-42
	030.4.3.3	Checking the window wiper *PR746-1293/11216-; PR746-1294/11216-;*	030-42
	030.4.3.4	Oil samples and oil analysis *PR746-1293/11216-; PR746-1294/11216-;*	030-42
	030.4.3.5	Wet cleaning the machine *PR746-1293/11216-; PR746-1294/11216-;*	030-46
	030.4.3.6	Protecting the piston rods *PR746-1293/11216-; PR746-1294/11216-;*	030-48
	030.4.3.7	Taking the machine out of service *PR746-1293; PR746-1294;*	030-48
030.4.4	Drive group		030-48
	030.4.4.1	Check the engine oil level *PR746-1293/11216-; PR746-1294/11216-;*	030-48
	030.4.4.2	Changing engine oil *PR746-1293/11216-; PR746-1294/11216-;*	030-49
	030.4.4.3	Changing the lube oil filters *PR746-1293/11216-; PR746-1294/11216-;*	030-51
	030.4.4.4	Checking the diesel engine configuration and the belly pans for contamination and cleaning them *PR746-1293/11216-; PR746-1294/11216-;*	030-52
	030.4.4.5	Checking the ribbed V-belt and adjusting it if necessary *PR746-1293/11216-; PR746-1294/11216-;*	030-53
	030.4.4.6	Changing belt drive *PR746-1293/11216-; PR746-1294/11216-;*	030-55
	030.4.4.7	Check the Diesel engine arrangement for leaks and condition *PR746-1293/11216-; PR746-1294/11216-;*	030-56
	030.4.4.8	Check the supply and exhaust lines for mounting and leaks *PR746-1293/11216-; PR746-1294/11216-;*	030-56
	030.4.4.9	Check the electrical system of the Diesel engine *PR746-1293/11216-; PR746-1294/11216-;*	030-57
	030.4.4.10	Change oil separator filter cartridge *PR746-1293/11216-; PR746-1294/11216-;*	030-58

LWT/9087211/10/215-20190905_090946/en

	030.4.4.11	Checking and changing heat flange *PR746-1293/11216-; PR746-1294/11216-;*	030-59
	030.4.4.12	Checking engine mount, oil pan and engine brackets *PR746-1293/11216-; PR746-1294/11216-;*	030-61
	030.4.4.13	Checking tightening torque of profile clamp *PR746-1293/11216-; PR746-1294/11216-;*	030-61
	030.4.4.14	Notes for work on the fuel system *PR746-1293/11216-; PR746-1294/11216-;*	030-61
	030.4.4.15	Fuel preliminary filter: Drain the condensation *PR746-1293/11216-; PR746-1294/11216-;*	030-62
	030.4.4.16	Fuel tank: Drain condensation and sediments *PR746-1293/11216-; PR746-1294/11216-;*	030-62
	030.4.4.17	Change fuel preliminary filter cartridge *PR746-1293/11216-; PR746-1294/11216-;*	030-64
	030.4.4.18	Changing fuel fine filter *PR746-1293/11216-; PR746-1294/11216-;*	030-65
	030.4.4.19	Empty and clean the fuel tank *PR746-1293/11216-; PR746-1294/11216-;*	030-67
	030.4.4.20	Venting fuel system *PR746-1293/11216-; PR746-1294/11216-;*	030-69
	030.4.4.22	Replacing the air filter *PR746-1293/11216-; PR746-1294/11216-;*	030-71
	030.4.4.23	Clean the dust discharge valve *PR746-1293/11216-; PR746-1294/11216-;*	030-74
	030.4.4.24	Splitterbox: Check the oil level *PR746-1293/11216-; PR746-1294/11216-;*	030-75
	030.4.4.25	Splitterbox: Changing the oil *PR746-1293/11216-; PR746-1294/11216-;*	030-75
030.4.5	Cooling system		030-77
	030.4.5.1	Check the coolant level and refill *PR746-1293/11216-; PR746-1294/11216-;*	030-77
	030.4.5.2	Clean the cooling system *PR746-1293/11216-; PR746-1294/11216-;*	030-79
	030.4.5.3	Check the cooling system *PR746-1293/11216-; PR746-1294/11216-;*	030-82
	030.4.5.4	Check the antifreeze concentration in the coolant. *PR746-1293/11216-; PR746-1294/11216-;*	030-84
	030.4.5.5	Change the coolant *PR746-1293/11216-; PR746-1294/11216-;*	030-90
030.4.6	Travel hydraulics		030-93
	030.4.6.1	Changing the supply circuit filter *PR746-1293/11216-; PR746-1294/11216-;*	030-93
030.4.7	Hydraulic components		030-97

LWT/90872111/10/215-20190905_090946/en

	030.4.7.1	Check the oil level in the hydraulic tank and add oil *PR746-1293/11216-; PR746-1294/11216-;*	030-97
	030.4.7.2	Clean the magnetic rod on the hydraulic tank *PR746-1293/11216-; PR746-1294/11216-;*	030-100
	030.4.7.3	Checking the hydraulic system for function and leaks *PR746-1293/11216-; PR746-1294/11216-;*	030-101
	030.4.7.4	Clean the oil cooler *PR746-1293/11216-; PR746-1294/11216-;*	030-102
	030.4.7.5	Changing the hydraulic oil *PR746-1293/11216-; PR746-1294/11216-;*	030-103
	030.4.7.6	Draining water and sediments in the hydraulic tank *PR746-1293/11216-; PR746-1294/11216-;*	030-106
	030.4.7.7	Change the return filter insert *PR746-1293/11216-; PR746-1294/11216-;*	030-106
030.4.8	Electrical system		030-108
	030.4.8.1	Check the display unit and lighting *PR746-1293/11216-; PR746-1294/11216-;*	030-108
	030.4.8.2	Check the batteries *PR746-1293/11216-; PR746-1294/11216-;*	030-108
030.4.9	Travel gearbox		030-111
	030.4.9.1	Travel gearbox: checking the condition *PR746-1293; PR746-1294;*	030-111
	030.4.9.2	Checking oil level *PR746-1293/11216-; PR746-1294/11216-;*	030-111
	030.4.9.3	Changing the oil *PR746-1293/11216-; PR746-1294/11216-;*	030-112
	030.4.9.4	Checking the oil level in the duo cone (slip ring) area *PR746-1293/11216-; PR746-1294/11216-;*	030-113
	030.4.9.5	Change the oil in the duo cone (slip ring) area *PR746-1293/11216-; PR746-1294/11216-;*	030-115
030.4.10	Travel gear, axles, tyres, drive shafts		030-119
	030.4.10.1	Checking the nuts and bolts of the travel gear components are firmly seated *PR746-1293/11216-; PR746-1294/11216-;*	030-119
	030.4.10.2	Checking the carrier rollers, track rollers and idlers for tightness *PR746-1293/11216-; PR746-1294/11216-;*	030-121
	030.4.10.3	Check and adjust the idler guides *PR746-1293/11216-; PR746-1294/11216-;*	030-121
	030.4.10.4	Check and adjust the chain tension *PR746-1293/11216-; PR746-1294/11216-;*	030-125
	030.4.10.5	Change the chain *PR746-1293/11216-; PR746-1294/11216-;*	030-128
	030.4.10.6	Checking the travel gear wear *PR746-1293/11216-; PR746-1294/11216-;*	030-134

LWT/9087211/10/215-20190905_090946/en

030.4.10.7 Check the oil fill of the axle bearings
PR746-1293/11216-; PR746-1294/11216-; 030-134

030.4.10.8 Grease the equalizer bar bearing
PR746-1293/11216-; PR746-1294/11216-; 030-135

030.4.11 Working attachment 030-136

030.4.11.1 Checking the cutting edges, corners and ripper teeth for wear
PR746-1293/11216-; PR746-1294/11216-; 030-136

030.4.11.2 Check the center position and mounting
PR746-1293/11216-; PR746-1294/11216-; 030-136

030.4.11.3 Check the working equipment
PR746-1293/11216-; PR746-1294/11216-; 030-137

030.4.11.4 Checking the bearing points of the working attachment for play and wear
PR746-1293; PR746-1294; 030-137

030.4.11.5 Checking the mounting screws and pin retainers of the working attachment for tight seating
PR746-1293; PR746-1294; 030-139

030.4.11.6 Removing and installing the ripper tooth tips
PR746-1293/11216-; PR746-1294/11216-; 030-139

030.4.12 Operator's cab, heating, air conditioning 030-142

030.4.12.1 Checking the heating for function and leaks
PR746-1293/11216-; PR746-1294/11216-; 030-142

030.4.12.2 Clean and change the recirculating - fresh air filter
PR746-1293/11216-; PR746-1294/11216-; 030-143

030.4.12.3 Inspection of the air conditioning system by HVAC specialist staff
PR746-1293/11216-; PR746-1294/11216-; 030-144

030.4.12.4 Check the compressor mounting
PR746-1293/11216-; PR746-1294/11216-; 030-144

030.4.12.5 To check the capacitor
PR746-1293/11216-; PR746-1294/11216-; 030-145

030.5 Testing and adjustment checklist
PR746-1293/11216-; PR746-1294/11216-; 030-146

030.5.1 Adjustment checklist 030-146

030.5.2 Track Components Check List 030-157

030.5.2.1 Test report 030-157

030.5.2.2 Wear data 030-161

030.6 Check and adjustment tasks 030-164

030.6.1 Safety instructions
PR746-1293; PR746-1294; 030-164

030.6.2 Overall machine 030-165

030.6.2.1 Preparations for adjustment procedures
PR746-1293/11216-; PR746-1294/11216-; 030-165

LWT/90872111/10/215-20190905_090946/en

	030.6.2.2	Visual inspection and maintenance *PR746-1293/11216-; PR746-1294/11216-;*	030-167
	030.6.2.3	Bringing machine to operating temperature *PR746-1293/11216-; PR746-1294/11216-;*	030-168
	030.6.2.3	Various procedures can be selected for reaching the operating temperature: *PR746-1293/11216-; PR746-1294/11216-;*	030-168
030.6.3	Drive group		030-170
	030.6.3.1	Engine speed controller of diesel engine — determining adjustment range *PR746-1293/11216-; PR746-1294/11216-;*	030-170
030.6.4	Cooling system		030-172
	030.6.4.1	Checking the stand-by pressure for the fan control *PR746-1293/11216-; PR746-1294/11216-;*	030-172
	030.6.4.2	Checking pressure relief valve – fan motor and fan control *PR746-1293/11216-; PR746-1294/11216-;*	030-175
030.6.5	Working hydraulics		030-180
	030.6.5.1	Checking the standby pressure *PR746-1293/11216-; PR746-1294/11216-;*	030-180
	030.6.5.2	Checking the primary pressure relief valve on the control valve block *PR746-1293/11216-; PR746-1294/11216-;*	030-181
	030.6.5.3	Checking the secondary pressure relief valve on the control valve block *PR746-1293/11216-; PR746-1294/11216-;*	030-182
	030.6.5.4	Checking the pressure cut off *PR746-1293/11216-; PR746-1294/11216-;*	030-184
	030.6.5.5	Checking the pressure difference HD-LS *PR746-1293/11216-; PR746-1294/11216-;*	030-185
	030.6.5.6	Checking the nitrogen fill in the hydro accumulator *PR746-1293/11216-; PR746-1294/11216-;*	030-186
030.6.6	Travel hydraulics		030-186
	030.6.6.1	Checking the supply pressure of the variable pump *PR746-1293/11216-; PR746-1294/11216-;*	030-186
	030.6.6.2	Checking the pressure limitation for high pressure *PR746-1293/11216-; PR746-1294/11216-;*	030-187
030.6.7	Electrical system		030-188
	030.6.7.1	Calibrating the hydrostat *PR746-1293/11216-; PR746-1294/11216-;*	030-188
	030.6.7.2	Checking travel joystick *PR746-1293/11216-; PR746-1294/11216-;*	030-199
	030.6.7.3	Calibrating inching brake pedal *PR746-1293/11216-; PR746-1294/11216-;*	030-212

LWT/9087211/10/215-20190905_090946/en

030.6.7.4 Brake test
PR746-1293/11216-; PR746-1294/11216-; 030-219

030.6.7.5 Overspeed safety test (option)
PR746-1293/11216-; PR746-1294/11216-; 030-223

030.6.7.6 Parameter adjustment options
PR746-1293/11216-; PR746-1294/11216-; 030-225

040 Drive group 040-1

040.1 Diesel engine 040-2

040.1.1 Diesel engine - full overview
PR746-1293/11216-; PR746-1294/11216-; 040-2

040.1.2 Fuel system 040-7

040.1.2.1 Fuel system
PR746-1293/11216-; PR746-1294/11216-; 040-7

040.1.2.2 Fuel quantity sensor
PR746-1293/11216-; PR746-1294/11216-; 040-8

040.1.2.3 Fuel filter
PR746-1293/11216-; PR746-1294/11216-; 040-9

040.1.2.4 Fuel tank
PR746-1293/11216-; PR746-1294/11216-; 040-10

040.1.3 Air filter system 040-11

040.1.3.1 Air filter system
PR746-1293/11216-; PR746-1294/11216-; 040-12

040.1.4 Exhaust system 040-13

040.1.4.1 Exhaust system - Full overview
PR746-1293/11216-; PR746-1294/11216-; 040-14

040.1.4.2 Selective catalytic reduction - SCR
PR746-1293/11216-; PR746-1294/11216-; 040-15

040.1.5 Diesel engine mounting
PR746-1293/11216-; PR746-1294/11216-; 040-18

040.2 Clutch
PR746-1293/11216-; PR746-1294/11216-; 040-20

040.3 Splitterbox
PR746-1293/11216-; PR746-1294/11216-; 040-22

040.4 Couplings - Pump output
PR746-1293/11216-; PR746-1294/11216-; 040-25

050 Cooling system 050-1

050.1 Cooling system, complete
PR746-1293/11216-; PR746-1294/11216-; 050-2

050.2 Cooler arrangement 050-5

050.2.1 Combi cooler
PR746-1293/11216-; PR746-1294/11216-; 050-5

LWT/90872111/10/215-20190905_090946/en

050.3 Hydraulic 050-11

050.3.1 Regulating pump
PR746-1293/11216-; PR746-1294/11216-; 050-11

050.3.2 Vane cell pump, cooler for charge air and water, and gear motor oil cooler
PR746-1293/11216-; PR746-1294/11216-; 050-14

060 Working hydraulics 060-1

060.1 Full overview - Working hydraulic
PR746-1293/11216-; PR746-1294/11216-; 060-2

060.2 Regulating pump 060-14

060.2.1 Regulating pump - Full overview
PR746-1293/11216-; PR746-1294/11216-; 060-15

060.3 Proportional control valve block 060-21

060.3.1 Proportional control valve block - Full overview
PR746-1293/11216-; PR746-1294/11216-; 060-22

060.4 Pilot control Working hydraulic 060-28

060.4.1 Pilot control - Full overview
PR746-1293/11216-; PR746-1294/11216-; 060-28

060.5 Hydraulic cylinder 060-35

060.5.1 Lift cylinder
PR746-1293/11216-; PR746-1294/11216-; 060-35

060.5.2 Tilt cylinder
PR746-1293/11216-; PR746-1294/11216-; 060-36

070 Travel hydraulics 070-1

070.1 Travel hydraulics overview
PR746-1293/11216-; PR746-1294/11216-; 070-2

070.2 Gear pump - replenishing
PR746-1293/11216-; PR746-1294/11216-; 070-12

070.3 Variable displacement pump
PR746-1293/11216-; PR746-1294/11216-; 070-14

070.4 Variable displacement motors 070-23

070.4.1 Variable displacement motors - Full overview
PR746-1293/11216-; PR746-1294/11216-; 070-23

070.5 Distributor block 070-32

070.5.1 Parking brake, solenoid valve
PR746-1293/11216-; PR746-1294/11216-; 070-33

080 Hydraulic components 080-1

080.1 Hydraulic cylinder 080-2

LWT/9087211/10/215-20190905_090946/en

080.1.1 Ripper cylinder
PR746-1293/11216-; PR746-1294/11216-; 080-2

080.1.2 Valves
PR746-1293/11216-; PR746-1294/11216-; 080-3

080.2 Hydraulic tank 080-16

080.2.1 Hydraulic tank
PR746-1293/11216-; PR746-1294/11216-; 080-16

100 Brake system 100-1

100.1 Inching brake pedal 100-2

100.1.1 Speed reduction pedal
PR746-1293/11216-; PR746-1294/11216-; 100-2

110 Electrical system 110-1

110.1 Electrical system - Full overview
PR746-1293/11216-; PR746-1294/11216-; 110-2

110.2 Lighting system
PR746-1293/11216-; PR746-1294/11216-; 110-5

110.3 Circuit diagrams
PR746-1293/11216-; PR746-1294/11216-; 110-8

110.4 Electrical components in operator's cab
PR746-1293/11216-; PR746-1294/11216-; 110-9

110.4.2 Central control (Master 100)
PR746-1293/11216-; PR746-1294/11216-; 110-16

110.4.3 Travel sensor
PR746-1293/11216-; PR746-1294/11216-; 110-18

110.4.4 Speed control
PR746-1293/11216-; PR746-1294/11216-; 110-20

110.5 Electrical components - Diesel engine
PR746-1293/11216-; PR746-1294/11216-; 110-22

110.6 Electrical components - Main frame
PR746-1293/11216-; PR746-1294/11216-; 110-26

110.7 Electrical components Compartments 110-31

110.7.1 Battery compartment
PR746-1293/11216-; PR746-1294/11216-; 110-31

110.7.2 Fuel tank compartment
PR746-1293/11216-; PR746-1294/11216-; 110-33

110.7.3 Central electrical system compartment
PR746-1293/11216-; PR746-1294/11216-; 110-37

110.7.4 Hydraulic tank
PR746-1293/11216-; PR746-1294/11216-; 110-44

110.8 Display unit
PR746-1293/11216-; PR746-1294/11216-; 110-46

LWT/90872111/10/215-20190905_090946/en

120 Travel gearbox 120-1

120.1 Travel gear
PR746-1293/11216-; PR746-1294/11216-; 120-2

120.2 Brake system
PR746-1293/11216-; PR746-1294/11216-; 120-9

120.3 Duo cone slipring seal
PR746-1293/11216-; PR746-1294/11216-; 120-10

120.4 External oil supply
PR746-1293/11216-; PR746-1294/11216-; 120-11

130 Travel gear, axles, tyres, drive shafts 130-1

130.1 Travel gear frame 130-2

130.1.1 Support frame
PR746-1293/11216-; PR746-1294/11216-; 130-3

130.2 Idler
PR746-1293/11216-; PR746-1294/11216-; 130-5

130.3 Tension unit
PR746-1293/11216-; PR746-1294/11216-; 130-7

130.4 Tension unit – removal
PR746-1293/11216-; PR746-1294/11216-; 130-9

130.4.1.1 Remove the cover on the track roller frame 130-10

130.4.1.2 Position of tension unit grease nipple 130-11

130.4.1.3 Push the pin in 130-11

130.4.1.4 Removal of cover 130-12

130.4.1.5 Grease nipple with twist guard 130-12

130.4.1.6 Place a mark 130-13

130.4.1.7 Installation of the assembly tool 130-13

130.4.1.8 Adjust the assembly tool 130-14

130.4.1.9 Clamp on the assembly tool 130-14

130.4.1.10 Press in the tension unit 130-16

130.4.1.11 Removal of the tension unit 130-17

130.5 Track roller
PR746-1293/11216-; PR746-1294/11216-; 130-18

130.6 Carrier roller
PR746-1293/11216-; PR746-1294/11216-; 130-19

130.7 Function, wear and evaluation
PR746-1293; PR746-1294; 130-20

140 Steel components Basic machine 140-1

140.1 Lift cylinder suspension
PR746-1293/11216-; PR746-1294/11216-; 140-2

LWT/9087211/10/215-20190905_090946/en

140.2 Equalizer bar
PR746-1293/11216-; PR746-1294/11216-; 140-3

140.3 Push frame (outside)
PR746-1293/11216-; PR746-1294/11216-; 140-6

150 Working attachment 150-1

150.1 Straight blade
PR746-1293/11216-; PR746-1294/11216-; 150-2

150.2 Hydraulic cutting angle adjustment
PR746-1293/11216-; PR746-1294/11216-; 150-3

150.3 Ripper
PR746-1293/11216-; PR746-1294/11216-; 150-10

150.4 Cutting angle adjustment - Ripper
PR746-1293/11216-; PR746-1294/11216-; 150-17

160 Operator's cab, heating, air conditioning 160-1

160.1 Operator’s platform 160-2

160.1.1 Operator's platform Attachments
PR746-1293/11216-; PR746-1294/11216-; 160-2

160.1.2 Operator's platform bearing
PR746-1293/11216-; PR746-1294/11216-; 160-3

160.1.3 Support cylinder
PR746-1293/11216-; PR746-1294/11216-; 160-6

160.2 Operator's cab 160-10

160.2.1 Operator's seat
PR746-1293/11216-; PR746-1294/11216-; 160-10

160.3 Heating, ventilation, air conditioning 160-11

160.3.1 Heating and air conditioning system 160-11

160.3.1.1 Heating, air conditioning and ventilation
PR746-1293/11216-; PR746-1294/11216-; 160-11

190 Options 190-1

190.1 Refueling pump
PR746-1293/11216-; PR746-1294/11216-; 190-2

190.2 Reversible fan drive
PR746-1293; PR746-1294; 190-8

200 Service codes, Diagnostics 200-1

200.2 Testing and adjustment software 200-2

200.2.1 Wizard test and adjustment software 200-2

200.2.1.1 General 200-2

200.2.1.2 Symbols 200-3

LWT/90872111/10/215-20190905_090946/en

200.2.1.3 Information window 200-73

LWT/9087211/10/215-20190905_090946/en

Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com